



Year: 2015

Consensus recommendations for a standardized Brain Tumor Imaging Protocol in clinical trials

Ellingson, B M ; Bendszus, M ; Boxerman, J ; Barboriak, D ; Erickson, B J ; Smits, M ; Nelson, S J ; Gerstner, E ; Alexander, B ; Goldmacher, G ; Wick, W ; Vogelbaum, M ; Weller, M ; Galanis, E ; Kalpathy-Cramer, J ; Shankar, L ; Jacobs, P ; Pope, W B ; Yang, D ; Chung, C ; Knopp, M V ; Cha, S ; van den Bent, M J ; Chang, S ; Al Yung, W K ; Cloughesy, T F ; Wen, P Y ; Gilbert, M R

Abstract: A recent joint meeting was held on January 30, 2014, with the US Food and Drug Administration (FDA), National Cancer Institute (NCI), clinical scientists, imaging experts, pharmaceutical and biotech companies, clinical trials cooperative groups, and patient advocate groups to discuss imaging endpoints for clinical trials in glioblastoma. This workshop developed a set of priorities and action items including the creation of a standardized MRI protocol for multicenter studies. The current document outlines consensus recommendations for a standardized Brain Tumor Imaging Protocol (BTIP), along with the scientific and practical justifications for these recommendations, resulting from a series of discussions between various experts involved in aspects of neuro-oncology neuroimaging for clinical trials. The minimum recommended sequences include: (i) parameter-matched precontrast and postcontrast inversion recovery-prepared, isotropic 3D T1-weighted gradient-recalled echo; (ii) axial 2D T2-weighted turbo spin-echo acquired after contrast injection and before postcontrast 3D T1-weighted images to control timing of images after contrast administration; (iii) precontrast, axial 2D T2-weighted fluid-attenuated inversion recovery; and (iv) precontrast, axial 2D, 3-directional diffusion-weighted images. Recommended ranges of sequence parameters are provided for both 1.5 T and 3 T MR systems.

DOI: <https://doi.org/10.1093/neuonc/nov095>

Posted at the Zurich Open Repository and Archive, University of Zurich

ZORA URL: <https://doi.org/10.5167/uzh-114447>

Journal Article

Accepted Version

Originally published at:

Ellingson, B M; Bendszus, M; Boxerman, J; Barboriak, D; Erickson, B J; Smits, M; Nelson, S J; Gerstner, E; Alexander, B; Goldmacher, G; Wick, W; Vogelbaum, M; Weller, M; Galanis, E; Kalpathy-Cramer, J; Shankar, L; Jacobs, P; Pope, W B; Yang, D; Chung, C; Knopp, M V; Cha, S; van den Bent, M J; Chang, S; Al Yung, W K; Cloughesy, T F; Wen, P Y; Gilbert, M R (2015). Consensus recommendations for a standardized Brain Tumor Imaging Protocol in clinical trials. *Neuro-Oncology*, 17(9):1188-1198.

DOI: <https://doi.org/10.1093/neuonc/nov095>

Neuro-Oncology

Consensus Recommendations for a Standardized Brain Tumor Imaging Protocol (BTIP) in Clinical Trials

--Manuscript Draft--

Manuscript Number:	N-O-D-15-00169R1
Full Title:	Consensus Recommendations for a Standardized Brain Tumor Imaging Protocol (BTIP) in Clinical Trials
Article Type:	Review
Keywords:	Standardized MRI Protocol; BTIP; glioblastoma; Clinical Trials
Corresponding Author:	Benjamin M Ellingson, Ph.D. David Geffen School of Medicine at UCLA Los Angeles, CA UNITED STATES
Corresponding Author Secondary Information:	
Corresponding Author's Institution:	David Geffen School of Medicine at UCLA
Corresponding Author's Secondary Institution:	
First Author:	Benjamin M Ellingson, Ph.D.
First Author Secondary Information:	
Order of Authors:	Benjamin M Ellingson, Ph.D.
	Martin Bendszus, M.D.
	Jerrold Boxerman
	Daniel Barboriak
	Bradley Erickson
	Marion Smits
	Sarah Nelson
	Elizabeth Gerstner
	Brian Alexander
	Gregory Goldmacher
	Wolfgang Wick
	Michael Vogelbaum
	Michael Weller
	Evanthia Galanis
	Jayashree Kalpathy-Cramer
	Lalitha Shankar
	Paula Jacobs
	Whitney Pope
	Dewen Yang
	Caroline Chung
Michael Knopp	
Soonme Cha	

	Martin van den Bent
	Susan Chang
	W.K. Al Yung
	Timothy F Cloughesy
	Patrick Y Wen
	Mark R Gilbert
Order of Authors Secondary Information:	
Manuscript Region of Origin:	UNITED STATES
Abstract:	<p>A recent joint meeting was held on January 30, 2014, among the U.S. Food and Drug Administration (FDA), National Cancer Institute (NCI), clinical scientists, imaging experts, pharmaceutical and biotech companies, clinical trials cooperative groups, and patient advocate groups to discuss imaging endpoints for clinical trials in glioblastoma. This workshop developed a set of priorities and action items including the creation of a standardized MRI protocol for multicenter studies. The current document outlines consensus recommendations for a standardized Brain Tumor Imaging Protocol (BTIP), along with the scientific and practical justifications for these recommendations, resulting from a series of discussions between various experts involved in aspects of neuro-oncology neuroimaging for clinical trials. The minimum recommended sequences include: 1) parameter matched pre- and post-contrast inversion-recovery (IR)-prepared, isotropic 3D T1-weighted GRE; 2) axial 2D T2-weighted turbo spin echo acquired after contrast injection and before post-contrast 3D T1-weighted images to control timing of images after con-trast administration; 3) pre-contrast, axial 2D T2-weighted FLAIR; and 4) pre-contrast, axial 2D, 3-directional diffusion-weighted images. Recommended ranges of sequence parameters are provided for both 1.5T and 3T MR systems.</p>

**Consensus Recommendations for a
Standardized Brain Tumor Imaging Protocol (BTIP) in Clinical Trials**

Benjamin M. Ellingson, Ph.D.^{1,2,†,§,¥,æ,Ω}, Martin Bendszus, M.D.^{3,β},
 Jerrold Boxerman, M.D., Ph.D.^{4,¥,Ω,£}, Daniel Barboriak, M.D.^{5,¥,æ,Ω},
 Bradley J. Erickson, M.D., Ph.D.^{6,◇,æ,Ω}, Marion Smits, M.D.^{7,β}, Sarah J. Nelson, Ph.D.^{8,§}
 Elizabeth Gerstner, M.D.^{9,†}, Brian Alexander, M.D.¹⁰,
 Gregory Goldmacher, M.D., Ph.D.¹¹, Wolfgang Wick, M.D.^{12,β},
 Michael Vogelbaum, M.D.^{13,¢}, Michael Weller, M.D.¹⁴, Evanthia Galanis, M.D.^{15,◇},
 Jayashree Kalpathy-Cramer, Ph.D.¹⁶, Lalitha Shankar, M.D., Ph.D.¹⁷,
 Paula Jacobs, Ph.D.¹⁷, Whitney B. Pope, M.D., Ph.D.^{2,Ω},
 Dewen Yang, Ph.D.¹¹, Caroline Chung, M.D.¹⁸, Michael V. Knopp, M.D., Ph.D.^{19,æ},
 Soonme Cha, M.D.^{8,21}, Martin .J. van den Bent, M.D.^{20,β}, Susan Chang, M.D.²¹,
 W.K. Al Yung, M.D.²², Timothy F. Cloughesy, M.D.^{1,23},
 Patrick Y. Wen, M.D.^{10,†}, Mark R. Gilbert, M.D.^{24,¢},
 and the Jumpstarting Brain Tumor Drug Development Coalition Imaging Standardization
 Steering Committee*

*Additional members of the Jumpstarting Brain Tumor Drug Development Coalition Imaging Standardization Steering Committee:

Andrew Whitney, J.D.²⁵, David Sandak²⁶, Al Musella, D.P.M.²⁷, Chas Haynes, J.D.²⁸,
 Max Wallace²⁶, David F. Arons, J.D.²⁹, Ann Kingston, Ph.D.²⁹

Affiliations:

¹ UCLA Neuro-Oncology Program & UCLA Brain Tumor Imaging Laboratory (BTIL), David Geffen School of Medicine, University of California – Los Angeles, Los Angeles, CA

² Department of Radiological Sciences, David Geffen School of Medicine, University of California – Los Angeles, Los Angeles, CA

³ Department of Neuroradiology, Heidelberg University Hospital, Heidelberg, Germany

⁴ Department of Diagnostic Imaging, Warne Alpert Medical School, Brown University, Providence, RI

⁵ Department of Neuroradiology, Duke University School of Medicine, Durham, NC

⁶ Department of Radiology, Mayo Clinic, Rochester, MN

⁷ Department of Radiology, Erasmus MC University, Rotterdam, Netherlands

⁸ Department of Radiology and Biomedical Imaging, University of California – San Francisco, San Francisco, CA

⁹ Department of Neurology, Massachusetts General Hospital, Harvard Medical School, Boston, MA

¹⁰ Center for Neuro-Oncology, Dana-Farber/Brigham and Women's Cancer Center, Harvard Medical School, Boston, MA

¹¹ Medical and Scientific Affairs, ICON Medical Imaging, Warrington, PA

¹² Department of Neurooncology, National Center of Tumor Disease, University Clinic Heidelberg, Heidelberg, Germany

¹³ Department of Neurological Surgery, Brain Tumor and Neuro-Oncology Center, Cleveland Clinic, Cleveland, OH

- ¹⁴ Department of Neurology, University Hospital Zurich, Zurich, Switzerland
- ¹⁵ Division of Medical Oncology, Department of Oncology, Mayo Clinic, Rochester, MN
- ¹⁶ Martinos Center for Biomedical Imaging, Massachusetts General Hospital and Harvard Medical School, Boston, MA
- ¹⁷ Division of Cancer Treatment and Diagnosis, National Cancer Institute (NCI), Bethesda, MD
- ¹⁸ Department of Radiation Oncology, University of Toronto & Princess Margaret Hospital, Toronto, Ontario, Canada
- ¹⁹ Wright Center for Innovation in Biomedical Imaging, Division of Imaging Science, Wexner Medical Center, Ohio State University, Columbus, OH
- ²⁰ Department of Neuro-Oncology, Erasmus MC Cancer Institute, Rotterdam, Netherlands
- ²¹ Department of Neurological Surgery, University of California – San Francisco, San Francisco, CA
- ²² Department of Neuro-Oncology, Division of Cancer Medicine, The University of Texas MD Anderson Cancer Center, Houston, TX
- ²³ Department of Neurology, David Geffen School of Medicine, University of California – Los Angeles, Los Angeles, CA
- ²⁴ Neuro-Oncology Branch, National Cancer Institute (NCI), Bethesda, MD
- ²⁵ Morgan Lewis & Bockius LLP, Philadelphia, PA
- ²⁶ Accelerate Brain Cancer Cure (ABC²), Washington, D.C.
- ²⁷ Musella Foundation, Hewlett, NY
- ²⁸ Collaborative Ependymoma Research Network, Dayton, OH

²⁹ National Brain Tumor Society (NBTS), Boston, MA

Additional Affiliations:

[†] Representative of the Adult Brain Tumor Consortium (ABTC)

[§] Representative of the Ivy Consortium for Early Phase Clinical Trials

[¥] Representative of the American College of Radiology Imaging Network (ACRIN)

^β Representative of the European Organisation for Research and Treatment of Cancer (EORTC)

[◇] Representative of the Alliance for Clinical Trials in Oncology

^æ Representative of the RSNA Quantitative Imaging Biomarker Alliance (QIBA)

^Ω Representative of the American Society of Neuroradiology (ASNR)

[£] Representative of the American Society of Functional Neuroradiology (ASFNR)

[¢] Representative of the Radiation Therapy Oncology Group (RTOG)

Word Count: 6926

Funding and Conflicts of Interest: *Roche/Genentech Research Grant (B.M.E.), Siemens Healthcare Research Grant (B.M.E.), National Brain Tumor Society Research Grant (B.M.E.)*

ABSTRACT

A recent joint meeting was held on January 30, 2014, among the U.S. Food and Drug Administration (FDA), National Cancer Institute (NCI), clinical scientists, imaging experts, pharmaceutical and biotech companies, clinical trials cooperative groups, and patient advocate groups to discuss imaging endpoints for clinical trials in glioblastoma. This workshop developed a set of priorities and action items including the creation of a standardized MRI protocol for multicenter studies. The current document outlines consensus recommendations for a standardized Brain Tumor Imaging Protocol (BTIP), along with the scientific and practical justifications for these recommendations, resulting from a series of discussions between various experts involved in aspects of neuro-oncology neuroimaging for clinical trials. The minimum recommended sequences include: 1) parameter matched pre- and post-contrast inversion-recovery (IR)-prepared, isotropic 3D T1-weighted GRE; 2) axial 2D T2-weighted turbo spin echo acquired after contrast injection and before post-contrast 3D T1-weighted images to control timing of images after contrast administration; 3) pre-contrast, axial 2D T2-weighted FLAIR; and 4) pre-contrast, axial 2D, 3-directional diffusion-weighted images. Recommended ranges of sequence parameters are provided for both 1.5T and 3T MR systems.

KEYWORDS

MRI; Glioblastoma; Clinical Trials; Brain Tumor Imaging Protocol

MANUSCRIPT BODY*Need for Increased Development of Therapeutics for Treating Brain Tumors*

Approximately 67,900 new primary central nervous system (CNS) tumors are diagnosed each year in the United States (21 per 100,000 persons) of which 44,910 are malignant.¹ Of these newly diagnosed tumors approximately 28% are gliomas, which constitute 80% of all malignant primary brain tumors.¹ Glioblastoma, the most common and aggressive type of glioma, is the focus of this document for two reasons. First, it is the most common form of high-grade glioma, accounting for 54% of all gliomas and 45% of all malignant primary CNS tumors,¹ thus it is a high priority area for therapeutic development. Second, glioblastoma is one of the most complex and treatment resistant brain tumors; therefore, improvements in drug development and measurement of tumor response to therapy in glioblastoma may allow advancement of these efforts for other types of brain tumors.

The current standard of care for newly diagnosed glioblastoma patients involves maximum safe surgical resection, followed by radiotherapy plus concomitant and adjuvant temozolomide,² but this treatment affords only a median survival of 14 – 16 months,³⁻⁶ and fewer than 10% of patients survive 5 years beyond diagnosis.⁷ Furthermore, very few therapeutic options exist for recurrent disease since patients with prior temozolomide exposure have progression-free survival (PFS) rates at 6 months of 20-40% regardless of chemotherapeutic intervention (e.g. nitrosoureas, temozolomide re-challenge, or bevacizumab).^{5,6,8} Thus, there is an urgent need for drug development in recurrent glioblastoma.

Role of Imaging in Brain Tumor Clinical Trials

Although overall survival (OS) is considered the gold standard for determining whether a cancer treatment is effective, OS may not directly reflect the specific impact of particular treatment regimens because of the confounding effects of known prognostic factors (e.g. age, tumor size, neurological status), use of additional therapies prior to or after the therapy of interest, and other health-related factors.^{9,10} Hence, PFS and *durable* objective response rate (ORR) are considered valuable end points for determining the relative value of a given treatment.¹¹ (Note that PFS also suffers from the impact of prognostic factors). Identifying response and progression has traditionally been based on neuroimaging, supported by clinical observation,¹² with limited utility of serum or cerebrospinal fluid markers of disease for gliomas. However, surrogate measures of tumor burden (e.g., area with contrast uptake), can suffer from issues associated with non-specificity of the surrogate, measurement variability, false positives, and discordance in radiographic interpretation between observers.¹³ Therefore, response assessment in neuro-oncology needs refinement to minimize intrinsic errors and to improve the accuracy of determining true response to a particular therapy.

A joint meeting was held on January 30, 2014, among the Food and Drug Administration (FDA), National Cancer Institute (NCI), clinical scientists, imaging experts, clinical trials cooperative groups, representatives from pharmaceutical and biotechnology companies, and patient advocate groups to discuss endpoints for clinical trials in glioblastoma.^{9,10,14,15} With only four drugs for glioblastoma approved by the FDA over the past 30 years (i.e. nitrosoureas, carmustine, temozolomide, and bevacizumab), significant costs associated with large studies, and few survival-extending breakthroughs, there is a need to quickly identify effective experimental therapies with a minimum of invested time and

cost. For example, three large Phase III trials were completed based on promising Phase II data, but failed to significantly extend OS.^{5,6,16} These failures highlight the need to optimize the use of imaging as a surrogate tool to better understand the response to novel therapeutics. To address these needs, a key recommendation arising from this workshop, with the encouragement of the FDA, was the development of a set of priorities and action items, including: 1) standardization of the MRI protocol for multicenter studies; 2) validating the use of volumetric analysis of T1 subtraction maps for defining treatment response and failure for use in drug approval studies; and 3) subsequent re-evaluation of the current response assessment in neuro-oncology (RANO) criteria with an effort to integrate standardized imaging and quantitative evaluations. These priorities set forth by the thought leaders in the neuro-oncology community, the *Jumpstarting Brain Tumor Drug Development Coalition* (consisting of the National Brain Tumor Society (NBTS), Society for Neuro-Oncology [SNO], Musella Foundation for Brain Tumor Research, and the Accelerate Brain Cancer Cure [ABC²]), the FDA, and NCI, represent the procedures necessary for validating and building confidence in order to use quantitative imaging surrogates as endpoints in glioblastoma clinical trials for drugs. Indeed, Dr. Richard Pazdur, Director of the FDA's Office of Hematology Oncology Products, shared; "During our participation in the Brain Tumor Endpoints Workshop we identified standardization of imaging data acquisition and analysis as a step towards increasing the reliability of radiographic endpoints in brain tumor clinical trials, and improving the ability to assess the impact of therapies in neuro-oncology."

The current document outlines the consensus recommendations for a standardized *Brain Tumor Imaging Protocol (BTIP)*, along with the scientific and practical justifica-

tions for these recommendations, resulting from a series of discussions between various experts in neuro-oncology neuroimaging for clinical trials. The recommendations in the current document are in direct response to the priorities that resulted from the workshop in January 2014, and are supported by the RANO working group.

Need for Imaging Standardization for Better Response Measures

In multicenter MRI studies, the heterogeneity of MR scanners and parameters (e.g. field strength, gradient system, manufacturer, sequences) must be considered. It is well known that even minor differences in hardware or sequence timing may result in significant changes in image contrast. Lesion contrast is also dependent on the magnetic field strength of the scanner,^{17,18} with higher field strengths showing higher contrast-to-noise compared with lower field strength scanners (e.g. 3T vs. 1.5T). Moreover, a variety of MR-protocols are commonly used for the same purpose, further hindering interpretation of imaging results from different treatment centers in the absence of tight control and standardization of image acquisition parameters.

Leveraging Lessons from the Alzheimer's Disease Neuroimaging Initiative (ADNI) Effort to Standardize Structural MRI Acquisition

Neuroimaging remains at the forefront of medical imaging technology and research; however, a lack of benchmarked standard acquisition protocols combined with rapidly evolving technologies can limit the ability to combine data in a multicenter fashion. This became readily apparent when attempting to study subtle structural changes in the brain related to degenerative diseases such as Alzheimer's disease. The subtle differences in

acquisition parameters and sequences, along with variations in MR system technologies and hardware, resulted in significant measurement discordance across centers, masking the effects of the disease. To standardize image acquisition to better understand Alzheimer's disease, the "Alzheimer's Disease Neuroimaging Initiative", or ADNI was launched in October 2004.^{19,20} This was a landmark effort to standardize brain imaging across clinical centers in the United States and Canada. ADNI was funded as a large public-private partnership between the National Institutes of Aging (NIA) and the National Institute of Biomedical Imaging and Bioengineering (NIBIB) of the National Institutes of Health (NIH), MR system manufacturers, several pharmaceutical companies (Pfizer, Wyeth, Eli Lilly, Merck, GlaxoSmithKline, AstraZeneca, Novartis, Eisai, Elan, Forest Laboratories, Bristol Meyers Squibb) and foundations (Alzheimer's Association, Institute for the Study of Aging).

One of the primary, tangible deliverables from ADNI was a standardized anatomic MRI protocol for accurate and reproducible brain imaging that is uniform across the major MR system manufacturers.²¹ The ADNI initiative produced a vendor neutral, standardized, inversion-recovery (IR) prepped volumetric T1-weighted gradient echo sequence for quantification of volumetric changes in brain structures, and a dual echo, proton-density T2-weighted turbo spin echo sequence for quantifying pathologic changes via estimates of tissue T2.²² The use of T1-weighted and T2-weighted images are of critical importance to brain tumor response assessment, as outlined in the RANO recommendations and discussed further in the current document. Since the imaging biomarkers and MRI pulse sequences of interest in ADNI are very similar to those required for measurement of brain tumor response to therapy, many of the ADNI recommendations were fo-

cused on the goal of expediting the process of developing a standardized anatomic MRI protocol for brain tumors and avoiding many of the pitfalls and expenses encountered by ADNI.

Development of MR Image Acquisition Standardization in the European Organization of Research and Treatment of Cancer (EORTC) Brain Tumor Group

The EORTC Brain Tumor Group (BTG) acknowledged the need for standardization of MR image acquisition in the context of clinical trials in 2010. A core group of BTG members including neuroradiologists, neuro-oncologists and MR physicists, with support from EORTC headquarters, developed both a basic and an advanced MR protocol. The basic protocol consisted of the core imaging sequences required to assess treatment response according to the RANO criteria, i.e. T1- and T2-weighted sequences. The basic protocol was deemed mandatory for all participating sites, while the advanced protocol was to be adopted by selected sites only. For both protocols, a balance was sought between feasibility and image quality. Since the protocol was required to be implemented in all participating sites throughout Europe, it needed to be feasible both in terms of available equipment and scan time. The main issue encountered when trying to implement this protocol was that sites were traditionally not selected on the basis of imaging facilities, but on their ability to recruit and enroll patients in clinical trials. Radiologists are commonly not involved in the impending EORTC trials, and generally no funding for any additional scan time is available in investigator initiated trials. The protocol therefore needed to seamlessly fit into the clinical routine, while ensuring sufficient image quality. The development phase was concluded in 2012, after which the protocols were implemented

in two newly opened trials: EORTC-26101 and EORTC-26091 (TAVAREC). General acceptance of the protocol was high, and only one site indicated that they would be unable to adhere to the protocol. After the initial rollout phase, major protocol violations were reduced markedly to below 10%. The excellent adherence indicates that the protocol could be implemented into the clinical routine without losing sites for recruitment, with a pragmatic but rigorous quality assurance mechanism in place (which is crucial in this setting). The BTIP described in the current document has drawn from the EORTC-BTG experience, and care has been taken to maintain the same level of feasibility.

Philosophical Considerations and Compromises

During the course of discussions with panel experts, many philosophical concepts and approaches were considered resulting in specific notable compromises. The concept of an “ideal” or “optimized” protocol is elusive and ill-defined in terms of the required performance measures used for optimization. Instead, a pragmatic approach was considered, striving for a balance between an “ideal” protocol that may be available only on select high-performance systems or at state-of-the-art academic centers, and a protocol that could reach large-scale compliance and acceptance from the community, including international participants. The goal of the initiative was not only to define a protocol for trials with reimbursement for imaging by the sponsor but also for use in investigator initiated trials without funding or even in daily practice. Thus the suggested protocol needs to approach what is used in clinical practice in terms of examination time and types of sequences. The concept of tightly controlling acquisition parameters to limit variability was felt to be desirable; however, this clearly must be balanced against the practicality of

employing such regulations at the large numbers of centers with variable imaging capabilities. With MR systems currently in use at large institutions dating back more than 20 years, a degree of flexibility was desired in order to allow these centers to still be involved in future clinical trials without significantly affecting image quality or performance. In short, perfect can be the enemy of good enough, and what is required here is an MRI protocol that is both adequate in terms of quality and feasible at the majority of institutions. Additionally, we attempted to think progressively and consider aspects related to the future of imaging response assessment, namely the potential use of volumetry (compared with current bidirectional assessments) for determining response, duration of response, as well as the potential for quantifying subclinical measures of tumor response including growth kinetics; use of T1 subtraction maps (compared with current evaluations on post-contrast T1-weighted images) to increase lesion conspicuity and more accurately quantify enhancing tumor burden; and the use of dual echo proton-density/T2-weighted images for estimating tissue T2 (instead of relying solely on T2-“weighted” images that are relatively non-specific for delineating nonenhancing tumor from vasogenic edema). As many new and promising pulse sequences may be more widely available in the future, the panel recommends that the current protocol serve as a well-needed *benchmark* for comparison of future sequences and imaging systems. Any new addition to the protocol should be evaluated for its potential to improve treatment evaluation with OS as the key endpoint. Lastly, the current recommended protocol was designed to obtain necessary content while minimizing total scan time, to ideally 30 minutes of actual image acquisition, as patient tolerance in this population can be a challenge and patient throughput is a primary concern for most imaging centers.

Recommended MRI Acquisition Protocols

The recommended minimum requirements for MR image acquisition for use in brain tumor clinical trials are outlined in *Table 1*. This protocol is applicable to both 1.5T and 3T scanners, although some modifications to scan parameters may be needed to ensure similar signal-to-noise ratio (SNR) and contrast-to-noise ratio (CNR) in the resulting images. Additional examples of compliant MR acquisition protocols specific to 3T and 1.5T scanners are found in *Tables 2 and 3*. The total amount of actual scan time (image acquisition only) was benchmarked at approximately 21 minutes and 30 seconds on a 3T Siemens Skyra with parallel imaging, suggesting the entire acquisition including set up and tear down can be performed in approximately 30 minutes using current 3T systems. Key elements of this protocol include: 1) a pre-contrast, three-dimensional, isotropic, IR-prepped T1-weighted gradient echo (IR-GRE) sequence; 2) an axial, two-dimensional T2-weighted fluid-attenuated inversion recovery (FLAIR) sequence obtained using a turbo-spin echo (TSE) readout; 3) an axial, two-dimensional, three-directional (isotropic) diffusion-weighted imaging (DWI) sequence obtained using echoplanar (EPI) or radial acquisition; 4) an axial, two-dimensional T2-weighted TSE sequence (dual echo preferred, but not required); and 5) a post-contrast, three-dimensional, isotropic, T1-weighted IR-GRE sequence with matching acquisition parameters to pre-contrast T1-weighted images.

Pre- and Post-Contrast Volumetric, IR-Prepared T1-Weighted Gradient Echo MRI

The use of pre- and post-contrast images (CT or MRI) has been the standard for detection, delineation, and response assessment of malignant brain tumors for more than 60 years. The most aggressive brain tumors are characterized by angiogenesis and studies have demonstrated a clear association between neovascularization and increased malignancy.^{23,24} This new vasculature is structurally abnormal, resulting in contrast agent leakage from the vascular to the extravascular, extracellular space and increased conspicuity of lesions on imaging in the general vicinity of active tumor. T1-weighted MRI sequences used after administration of a contrast agent that shortens T1 relaxation time are the standard for response assessment due to better soft tissue contrast and lack of ionizing radiation with MRI as opposed to contrast-enhanced CT.

The acquisition of three-dimensional, isotropic T1-weighted images allows for potential improvements in response assessment, including detection of smaller lesions, use of volumetric measurements of enhancing tumor burden and better alignment of tumor regions on subsequent follow up examinations. Data from the literature clearly indicates that volumetric measurements of tumor burden and response are equal to or better than 1D/2D measurements of tumor extent, especially with tumors that are irregular in shape such as glioblastoma.^{13,25-32} A higher inter-observer variability has been noted when assessments are made using bidirectional or unidirectional measurements compared with volumetric quantitation.³³⁻³⁷ Volumetric changes observed during therapy may be useful for quantification of trends in tumor growth or response that provide insight into whether a treatment is having an effect on the tumor despite lack of clear radiographic response according to the RANO criteria.³⁸ Additionally, a significant limitation of comparisons in

tumor size performed on relatively thick (~3-5mm) two-dimensional T1-weighted images includes the effects of slightly different slice prescriptions (e.g. different head tilt) on the ability to properly align similar slices for side-by-side comparison.³⁹ Acquisition of three-dimensional isotropic T1-weighted images will provide the ability to easily register or align images from subsequent follow-up time points to the baseline scans for more accurate comparisons of tumor size. Also, acquisition of three-dimensional isotropic T1-weighted images allows for resampling image data along different orientations without the need for additional MR acquisitions (e.g. in the sagittal or coronal planes, which are often desired for surgical and radiation therapy planning).

Three dimensional IR-GRE including MPRAGE or IR-SPGR is the most commonly used sequence for fast, three dimensional evaluation of tumor burden and has been studied extensively as a clinical tool in neuro-oncology for nearly twenty years⁴⁰⁻⁴⁴. The use of inversion preparation provides superior gray matter-to-white matter image contrast as well as significant enhancement of vascular structures; however, there is concern that inversion preparation may reduce the amount of lesion conspicuity. We considered potential use of three-dimensional sequences without inversion preparation, but felt the use of IR-GRE sequences were warranted given their current widespread use and extensive literature substantiating their clinical utility. Thus, we recommend three-dimensional isotropic T1-weighted IR-GRE acquisition, available on almost all MR systems as part of the standardized ADNI protocol, and in agreement with previous ACRIN, Alliance, and EORTC imaging guidelines for brain tumor clinical trials.

We also considered the potential use of a three-dimensional turbo spin echo (TSE) acquisition (e.g. SPACE [Siemens] or CUBE [General Electric]) instead of GRE, which

studies have suggested may provide a higher CNR between enhancing tumor and background tissues.⁴⁵ An inherent drawback of the use of three-dimensional GRE acquisition is the hyperintensity of blood vessels after contrast agent injection, which may make tumor segmentation more difficult due to increased signal from normal vasculature. The use of three-dimensional TSE with the use of a motion-sensitized driven-equilibrium preparation has been shown to overcome this limitation by suppressing signal from blood.⁴⁶ Despite the potential advantages of three-dimensional TSE over GRE, this sequence is not available on all MR systems, may require additional costs to purchase these sequences, and the specific pulse sequences are not necessarily standardized across vendors. Thus, we recommend three-dimensional isotropic T1-weighted images using a GRE acquisition, available on almost all MR systems as part of the standardized ADNI protocol, and in agreement with previous ACRIN, Alliance and EORTC imaging guidelines for brain tumor clinical trials.

The use of pre- and post-contrast T1-weighted images with matched sequence parameters also allows for use of contrast-enhanced T1-weighted subtraction for tumor visualization and quantification of enhancing tumor. By subtracting the voxel intensities obtained on pre-contrast T1-weighted images from post-contrast T1-weighted images, contrast agent accumulation can be more easily identified and quantified. This technique has been used in conjunction with MRI in brain tumors starting in the early 1990s, when Suto *et al.*⁴⁷ and Lloyd *et al.*⁴⁸ demonstrated the ability to identify enhancing tumors in the presence of blood products. Subsequent studies over the next few decades further established the added value of T1-weighted subtraction maps for lesion evaluation during standard therapies, and a recent study clearly demonstrated that enhancing tumor could

be better identified on T1-weighted subtraction maps during anti-angiogenic therapy,⁴⁹ where vascular permeability is markedly reduced. Additionally, T1-weighted subtraction maps have been shown to reduce the interobserver variability in lesion volume quantification, even in the presence of anti-angiogenic therapies,¹⁴ suggesting tumor response evaluation may be significantly improved through the use of T1-weighted subtraction techniques.

Ranges of sequence parameters were chosen for volumetric T1-weighted images based on known scanner and time limitations. An isotropic resolution of 1mm x 1mm x 1mm is recommended with full brain coverage (field-of-view of 25.6 cm), but this may not be possible with older MR systems or with adequate SNR at 1.5T. Therefore, we recommend acquiring volumetric T1-weighted images with a *maximum* resolution of 1.5mm x 1.5mm x 1.5mm, particularly for scanners at 1.5T. Additionally, sagittal image acquisition is recommended over axial acquisition, since sagittal acquisition is faster due to fewer required slices moving from left-to-right, although post-contrast flow artifacts have occasionally been observed. Although standard three-dimensional T1-weighted GRE sequences are preferred (e.g. MPRAGE [Siemens & Hitachi] or IR-SPGR [GE]), faster volumetric T1-weighted GRE sequences with internal motion compensation may also be used under similar acquisition parameters to reduce artifacts (e.g. BRAVO [GE] or VIBE [Siemens]). Additional scan parameters and details are documented in *Table 1*.

Institutions may desire to collect post-contrast T1-weighted images according to their own protocols in addition to the recommended three-dimensional isotropic T1-weighted images (e.g. two-dimensional, fat-saturated, T1-weighted TSE images). For compliance with the proposed protocol, we recommend additional post-contrast sequences be ac-

quired *after* three-dimensional, post-contrast T1-weighted images in order to ensure consistency in terms of the timing of contrast agent injection and acquisition of post-contrast T1-weighted images.

Use of Contrast Agents and Consistency of MR Scanners

Consistency in MR scanning hardware, software, contrast agent dose and contrast agent composition is absolutely imperative for maximizing accurate and reproducible serial measurements of tumor size. Patients involved in clinical trials should be scanned on the same physical MRI scanner during routine follow-up examinations to the extent this is both economically and technically feasible. If this ideal recommendation is not achievable, patients should at the very least be scanned on MRI scanners with the same field strength. Although it may be difficult to control the specific contrast agent used for clinical trials, it is critical to use contrast agents with the same chemical composition at each follow-up evaluation as baseline to limit potential variability arising from differences in contrast agent relaxivity (the amount of MR relaxation effects for a given concentration of contrast agent). Additionally, the precise dose and agent should be explicitly documented on the MR system during acquisition or labeled in the DICOM header (e.g. *Contrast_BolusAgent (0018,0010) = 1.5cc Gadovist*).

Axial, Two-Dimensional, T2-Weighted Turbo Spin Echo (Optional Dual-Echo Proton-Density/T2-Weighted TSE) MRI

Damadian⁵⁰ documented distinct differences in proton relaxation rates between normal and cancerous tissues as early as 1971, subsequently confirmed by various groups.⁵¹⁻

⁵³ Clinical diagnoses and monitoring of the non-enhancing tumor are often performed using T2-weighted images. Approximately 30-40% of brain tumor patients exhibit non-enhancing tumor progression prior to changes in contrast enhancement³², and some studies have described non-enhancing tumor growth and infiltration prior to emergence of contrast enhancing progressive disease during anti-angiogenic therapy.⁵⁴ Further, T2 hyperintense lesions are currently used to assess tumor burden in non-enhancing, low-grade glioma clinical trials. Therefore, use of T2-weighted images in the proposed protocol is recommended for all clinical brain tumor trials.

The protocol recommended for T2-weighted imaging was based on the parameters from ADNI as well as ACRIN, Alliance, and EORTC guidelines in existing trials. The recommended slice thickness for 3T scans is 3mm with no interslice gap, and 1.5T scanners should acquire images up to 4mm slice thickness with no interslice gap. (Older scanners still in operation may be allowed to acquire data up to a maximum of 5mm slice thickness (contiguous) or increase the number of averages with slice thicknesses ≤ 4 mm to ensure comparable SNR to other T2-weighted images acquired with newer systems, however, this should be avoided if possible). The recommended echo train length (ETL) is between 8 and 16, since an increase in ETL both accelerates acquisition as well as increases inaccuracies⁵⁵ associated with T2 mapping when using dual echo TSE to estimate tissue T2.

Timing of Contrast Agent Injection and Post-Contrast T1-Weighted Images

A high CNR between tumor and surrounding tissue is critical for precise measurement of tumor size. In addition to differences in sequences and sequence parameters,⁵⁶

the timing of contrast injection and acquisition of subsequent post-contrast T1-weighted images can also lead to variability in tumor size estimation. Dynamic contrast enhanced imaging has shown that the maximum contrast agent uptake typically occurs and stabilizes between 4 and 8 minutes after contrast agent application,⁵⁷ suggesting this may be the most effective window for acquiring post-contrast T1-weighted images for minimal variability in lesion size estimation caused by the timing of contrast agent administration. It is important to note that one inherent limitation to implementing a *minimal* time delay constraint is the preferential sensitivity to regions of the tumor with higher vascular permeability and/or blood flow. To standardize the minimal time between contrast agent injection and acquisition of post-contrast T1-weighted images we recommend acquiring T2-weighted images after injection and just prior to post-contrast T1-weighted images. Presumably, T2-weighted images utilizing spin echo or turbo spin echo acquisitions should be relatively insensitive to the presence of contrast agent in the vasculature, assuming transient changes have already occurred (i.e. assuming it is not during the first pass of the bolus injection), such that RANO interpretation and volumetric segmentation of T2-hyperintense regions should be minimally impacted.

Axial, Two-Dimensional, T2-Weighted Fluid-Attenuated Inversion Recovery (FLAIR) MRI

T2-weighted fluid-attenuated inversion recovery (FLAIR) MRI uses a combination of T1- and T2-weighting to suppress the signal originating from bulk fluid including cerebrospinal fluid. T2-weighted FLAIR techniques increase lesion conspicuity allowing for better visualization of vasogenic edema, surgical- and radiation- induced gliosis and infil-

trating tumor, particularly near the cortex and ventricles where cerebrospinal fluid can inhibit lesion detection. Additionally, T2-weighted FLAIR sequences (or T2-weighted images) are recommended for determination of non-enhancing tumor progression using RANO criteria.

The preferred protocol for T2-weighted FLAIR imaging was based on guidelines from the EORTC, ACRIN, and the Alliance. Similar to T2-weighted MRI, the recommended slice thickness for 3T scans is 3mm with no interslice gap, and 1.5T scanners should acquire images up to 4mm slice thickness with no interslice gap. Older scanners still in operation may be allowed to acquire data up to a maximum of 5mm slice thickness (contiguous) or increase the number of averages with slice thicknesses ≤ 4 mm to ensure comparable SNR to other T2-weighted FLAIR images acquired with newer systems. Also note that T2-weighted FLAIR MR images have intrinsically less SNR compared with standard T2-weighted MR images. The recommended echo train length (ETL) for T2-weighted FLAIR images is between 8 and 16.

Three-dimensional T2-weighted FLAIR techniques are commonly used on newer MR systems, but may not be available on all MR systems. A three-dimensional acquisition allows for slice reorientation in all three anatomical planes, the potential for quantification of T2-hyperintense lesion volumes, and is less sensitive to flow artifacts compared with 2D sequences. Given that three-dimensional acquisition is not universally available, the use of this technique, while strongly endorsed, is optional. Protocols or studies considering the use of 3D FLAIR should use the EORTC recommended parameters listed in the footnotes in *Table 1*.

Axial Two-Dimensional Diffusion Weighted Imaging (DWI)

Diffusion-sensitive MR techniques are routinely acquired as part of standard brain MRI protocols, primarily due to the high sensitivity to early ischemic injury as well as infection/abscess. Diffusion-weighted imaging (DWI) is sensitive to microscopic, sub-voxel water motion, resulting in relatively restricted diffusion in areas of tumor due to tightly packed tumor cells. Measures of the apparent diffusion coefficient (ADC) can be estimated from the DWI data, reflecting the general magnitude of water motion. In brain tumors, ADC has been shown to be a surrogate for cellularity in certain circumstances, with ADC inversely correlated with tumor cell density⁵⁸⁻⁶¹, suggesting DWI measures of ADC may be a useful biomarker for quantifying treatment response.⁶²

The recommended DWI protocol for routine evaluations is largely based on the EORTC, ACRIN, and Alliance recommended protocols as well as the International Society for Magnetic Resonance in Medicine (ISMRM) and NCI consensus recommendations from 2008.⁶² Specifically, we recommend three b -values be collected, one at $b=0$ s/mm² (no diffusion weighting), one mid-range b -value of 500 s/mm², and one higher b -value at $b=1000$ s/mm². These images should be collected in at least three directions (i.e. x , y , and z orientations with respect to the MR system frame of reference). Older MR scanners that are not capable of obtaining three or more unique b -values should use $b = 0$ and $b = 1000$ s/mm². The high b -value for routine DWI in clinical trials should be limited to $b=1000$ s/mm², resulting in a relative signal intensity of 37% of available MR signal if tissue has an ADC of 1 $\mu\text{m}^2/\text{ms}$, commonly associated with mean diffusivity of normal white matter. The recommended slice thickness for 3T scans is 3mm with no interslice gap, and 1.5T scanners should acquire images up to 4mm slice thickness with no interslice gap.

Older scanners still in operation may be allowed to acquire data up to a maximum of 5mm slice thickness (contiguous) or increase the number of averages with slice thicknesses ≤ 4 mm to ensure comparable SNR. Echo planar imaging (EPI) should be used when available. In the event of significant patient motion, a radial acquisition scheme may be used (e.g. BLADE [Siemens], PROPELLER [GE], MultiVane [Philips], RADAR [Hitachi], or JET [Toshiba]); however, this acquisition scheme can cause significant differences in ADC quantification and therefore should be used only if EPI is not an option. Additionally, radial acquisition techniques may require considerably more time.

Conclusion

The proposed recommendations for brain tumor MRI acquisition reflect a balance of state-of-the-art imaging technology with techniques that are practically employable across the majority of imaging centers involved in multicenter clinical trials. We specifically recommend this protocol for use in multicenter clinical trials to reduce variability associated with response assessment, but also encourage the use of this protocol in routine clinical practice where it will allow intra-institutional comparisons. The protocol was designed to allow flexibility in terms of adding subsequent imaging techniques, such as the addition of perfusion MRI prior to acquisition of post-contrast 3D T1-weighted images, the addition of susceptibility-weighted or gradient echo acquisition before contrast injection, or acquisition of post-contrast, 2D T1-weighted TSE images following post-contrast 3D T1-weighted image acquisition. The current recommendations were designed to serve as a benchmark for comparison to future improvements and evaluations.

The current recommendations solely involve acquisition of MR images and do not provide guidelines for the clinical interpretation or quantitation of tumor extent for the purposes of response evaluation. The current protocols were designed to be flexible and allow for both current RANO evaluations as well as the potential for future improvements including volumetric analyses.

ACKNOWLEDGEMENTS

The Jumpstarting Brain Tumor Drug Development Coalition Imaging Standardization Steering Committee would like to thank Drs. Joohee Sul and Daniel Krainak at the FDA for their review and input on these recommendations and this manuscript.

REFERENCES

1. Ostrom QT, Gittleman H, Liao P, et al. CBTRUS statistical report: primary brain and central nervous system tumors diagnosed in the United States in 2007-2011. *Neuro Oncol.* Oct 2014;16 Suppl 4:iv1-63.
2. Weller M, van den Bent M, Hopkins K, et al. EANO guideline for the diagnosis and treatment of anaplastic gliomas and glioblastoma. *Lancet Oncol.* Aug 2014;15(9):e395-403.
3. Stupp R, Mason WP, van den Bent MJ, et al. Radiotherapy plus concomitant and adjuvant temozolomide for glioblastoma. *N Engl J Med.* Mar 10 2005;352(10):987-996.
4. Gilbert MR, Wang M, Aldape KD, et al. Dose-dense temozolomide for newly diagnosed glioblastoma: a randomized phase III clinical trial. *J Clin Oncol.* Nov 10 2013;31(32):4085-4091.
5. Chinot OL, Wick W, Mason W, et al. Bevacizumab plus radiotherapy-temozolomide for newly diagnosed glioblastoma. *N Engl J Med.* Feb 20 2014;370(8):709-722.
6. Gilbert MR, Dignam JJ, Armstrong TS, et al. A randomized trial of bevacizumab for newly diagnosed glioblastoma. *N Engl J Med.* Feb 20 2014;370(8):699-708.
7. Stupp R, Hegi ME, Mason WP, et al. Effects of radiotherapy with concomitant and adjuvant temozolomide versus radiotherapy alone on survival in glioblastoma in a randomised phase III study: 5-year analysis of the EORTC-NCIC trial. *Lancet Oncol.* May 2009;10(5):459-466.

8. Weller M, Cloughesy T, Perry JR, Wick W. Standards of care for treatment of recurrent glioblastoma--are we there yet? *Neuro Oncol*. Jan 2013;15(1):4-27.
9. Ellingson BM, Wen PY, van den Bent MJ, Cloughesy TF. Pros and cons of current brain tumor imaging. *Neuro Oncol*. Oct 2014;16 Suppl 7:vii2-11.
10. Wen PY, Cloughesy TF, Ellingson BM, et al. Report of the Jumpstarting Brain Tumor Drug Development Coalition and FDA clinical trials neuroimaging endpoint workshop (January 30, 2014, Bethesda MD). *Neuro Oncol*. Oct 2014;16 Suppl 7:vii36-47.
11. Lamborn KR, Yung WK, Chang SM, et al. Progression-free survival: an important end point in evaluating therapy for recurrent high-grade gliomas. *Neuro Oncol*. Apr 2008;10(2):162-170.
12. Macdonald DR, Cascino TL, Schold SC, Jr., Cairncross JG. Response criteria for phase II studies of supratentorial malignant glioma. *J Clin Oncol*. Jul 1990;8(7):1277-1280.
13. Provenzale JM, Ison C, Delong D. Bidimensional measurements in brain tumors: assessment of interobserver variability. *AJR Am J Roentgenol*. Dec 2009;193(6):W515-522.
14. Ellingson BM, Bendszus M, Sorensen AG, Pope WB. Emerging techniques and technologies in brain tumor imaging. *Neuro Oncol*. Oct 2014;16 Suppl 7:vii12-23.
15. Reardon DA, Ballman KV, Buckner JC, Chang SM, Ellingson BM. Impact of imaging measurements on response assessment in glioblastoma clinical trials. *Neuro Oncol*. Oct 2014;16 Suppl 7:vii24-35.

16. Stupp R, Hegi ME, Gorlia T, et al. Cilengitide combined with standard treatment for patients with newly diagnosed glioblastoma with methylated MGMT promoter (CENTRIC EORTC 26071-22072 study): a multicentre, randomised, open-label, phase 3 trial. *Lancet Oncol.* Sep 2014;15(10):1100-1108.
17. Akeson P, Vikhoff B, Stahlberg F, Holtas S. Brain lesion contrast in MR imaging. Dependence on field strength and concentration of gadodiamide injection in patients and phantoms. *Acta Radiol.* Jan 1997;38(1):14-18.
18. Nobauer-Huhmann IM, Ba-Ssalamah A, Mlynarik V, et al. Magnetic resonance imaging contrast enhancement of brain tumors at 3 tesla versus 1.5 tesla. *Invest Radiol.* Mar 2002;37(3):114-119.
19. Mueller SG, Weiner MW, Thal LJ, et al. Ways toward an early diagnosis in Alzheimer's disease: the Alzheimer's Disease Neuroimaging Initiative (ADNI). *Alzheimers Dement.* Jul 2005;1(1):55-66.
20. Mueller SG, Weiner MW, Thal LJ, et al. The Alzheimer's disease neuroimaging initiative. *Neuroimaging Clin N Am.* Nov 2005;15(4):869-877, xi-xii.
21. Jack CR, Jr., Bernstein MA, Borowski BJ, et al. Update on the magnetic resonance imaging core of the Alzheimer's disease neuroimaging initiative. *Alzheimers Dement.* May 2010;6(3):212-220.
22. Leow AD, Klunder AD, Jack CR, Jr., et al. Longitudinal stability of MRI for mapping brain change using tensor-based morphometry. *Neuroimage.* Jun 2006;31(2):627-640.
23. Leon SP, Folkerth RD, Black PM. Microvessel density is a prognostic indicator for patients with astroglial brain tumors. *Cancer.* 1996;77:362-372.

24. Wesseling P, van der Laak JA, Link M, Teepen HL, Ruiter DJ. Quantitative analysis of microvascular changes in diffuse astrocytic neoplasms with increasing grade of malignancy. *Hum Pathol*. 1998;29(4):352-358.
25. Vos MJ, Uitdehaag BM, Barkhof F, et al. Interobserver variability in the radiological assessment of response to chemotherapy in glioma. *Neurology*. Mar 11 2003;60(5):826-830.
26. Dempsey MF, Condon BR, Hadley DM. Measurement of tumor "size" in recurrent malignant glioma: 1D, 2D, or 3D? *AJNR Am J Neuroradiol*. Apr 2005;26(4):770-776.
27. Chow KL, Gobin YP, Cloughesy T, Sayre JW, Villablanca JP, Vinuela F. Prognostic factors in recurrent glioblastoma multiforme and anaplastic astrocytoma treated with selective intra-arterial chemotherapy. *AJNR Am J Neuroradiol*. Mar 2000;21(3):471-478.
28. Reeves GI, Marks JE. Prognostic significance of lesion size for glioblastoma multiforme. *Radiology*. Aug 1979;132(2):469-471.
29. Wood JR, Green SB, Shapiro WR. The prognostic importance of tumor size in malignant gliomas: a computed tomographic scan study by the Brain Tumor Cooperative Group. *J Clin Oncol*. Feb 1988;6(2):338-343.
30. Warren KE, Patronas N, Aikin AA, Albert PS, Balis FM. Comparison of one-, two-, and three-dimensional measurements of childhood brain tumors. *J Natl Cancer Inst*. Sep 19 2001;93(18):1401-1405.
31. Galanis E, Buckner JC, Maurer MJ, et al. Validation of neuroradiologic response assessment in gliomas: measurement by RECIST, two-dimensional, computer-

- assisted tumor area, and computer-assisted tumor volume methods. *Neuro Oncol.* Apr 2006;8(2):156-165.
- 32.** Gallego Perez-Larraya J, Lahutte M, Petrirena G, et al. Response assessment in recurrent glioblastoma treated with irinotecan-bevacizumab: comparative analysis of the Macdonald, RECIST, RANO, and RECIST + F criteria. *Neuro Oncol.* May 2012;14(5):667-673.
- 33.** Hopper KD, Kasales CJ, Van Slyke MA, Schwartz TA, TenHave TR, Jozefiak JA. Analysis of interobserver and intraobserver variability in CT tumor measurements. *AJR Am J Roentgenol.* Oct 1996;167(4):851-854.
- 34.** Lavin PT, Flowerdew G. Studies in variation associated with the measurement of solid tumors. *Cancer.* Sep 1 1980;46(5):1286-1290.
- 35.** Quoix E, Wolkove N, Hanley J, Kreisman H. Problems in radiographic estimation of response to chemotherapy and radiotherapy in small cell lung cancer. *Cancer.* Aug 1 1988;62(3):489-493.
- 36.** Thiesse P, Ollivier L, Di Stefano-Louineau D, et al. Response rate accuracy in oncology trials: reasons for interobserver variability. Groupe Francais d'Immunotherapie of the Federation Nationale des Centres de Lutte Contre le Cancer. *J Clin Oncol.* Dec 1997;15(12):3507-3514.
- 37.** Warr D, McKinney S, Tannock I. Influence of measurement error on assessment of response to anticancer chemotherapy: proposal for new criteria of tumor response. *J Clin Oncol.* Sep 1984;2(9):1040-1046.

38. Wen PY, Macdonald DR, Reardon DA, et al. Updated response assessment criteria for high-grade gliomas: response assessment in neuro-oncology working group. *J Clin Oncol*. Apr 10 2010;28(11):1963-1972.
39. Reuter M, Gerstner ER, Rapalino O, Batchelor TT, Rosen B, Fischl B. Impact of MRI head placement on glioma response assessment. *J Neurooncol*. May 2014;118(1):123-129.
40. Brant-Zawadzki M, Gillan GD, Nitz WR. MP RAGE: a three-dimensional, T1-weighted, gradient-echo sequence--initial experience in the brain. *Radiology*. Mar 1992;182(3):769-775.
41. Brant-Zawadzki MN, Gillan GD, Atkinson DJ, Edalatpour N, Jensen M. Three-dimensional MR imaging and display of intracranial disease: improvements with the MP-RAGE sequence and gadolinium. *J Magn Reson Imaging*. Jul-Aug 1993;3(4):656-662.
42. Fellner F, Holl K, Held P, Fellner C, Schmitt R, Bohm-Jurkovic H. A T1-weighted rapid three-dimensional gradient-echo technique (MP-RAGE) in preoperative MRI of intracranial tumours. *Neuroradiology*. Apr 1996;38(3):199-206.
43. Runge VM, Kirsch JE, Thomas GS, Mugler JP, 3rd. Clinical comparison of three-dimensional MP-RAGE and FLASH techniques for MR imaging of the head. *J Magn Reson Imaging*. Jul-Aug 1991;1(4):493-500.
44. van den Hauwe L, Parizel PM, Van Goethem JW, De Schepper AM. Clinical usefulness of contrast-enhanced MP-RAGE of the brain. *Neuroradiology*. May 1996;38 Suppl 1:S14-19.

45. Downs RK, Bashir MH, Ng CK, Heidenreich JO. Quantitative contrast ratio comparison between T1 (TSE at 1.5T, FLAIR at 3T), magnetization prepared rapid gradient echo and subtraction imaging at 1.5T and 3T. *Quant Imaging Med Surg*. Jun 2013;3(3):141-146.
46. Nagao E, Yoshiura T, Hiwatashi A, et al. 3D turbo spin-echo sequence with motion-sensitized driven-equilibrium preparation for detection of brain metastases on 3T MR imaging. *AJNR Am J Neuroradiol*. Apr 2011;32(4):664-670.
47. Suto Y, Caner BE, Tamagawa Y, et al. Subtracted synthetic images in Gd-DTPA enhanced MR. *J Comput Assist Tomogr*. Sep-Oct 1989;13(5):925-928.
48. Lloyd GA, Barker PG, Phelps PD. Subtraction gadolinium enhanced magnetic resonance for head and neck imaging. *Br J Radiol*. Jan 1993;66(781):12-16.
49. Ellingson BM, Kim HJ, Woodworth DC, et al. Recurrent glioblastoma treated with bevacizumab: contrast-enhanced T1-weighted subtraction maps improve tumor delineation and aid prediction of survival in a multicenter clinical trial. *Radiology*. Apr 2014;271(1):200-210.
50. Damadian R. Tumor detection by nuclear magnetic resonance. *Science*. Mar 19 1971;171(3976):1151-1153.
51. Weisman ID, Bennett LH, Maxwell LR, Sr., Woods MW, Burk D. Recognition of cancer in vivo by nuclear magnetic resonance. *Science*. Dec 22 1972;178(4067):1288-1290.
52. Hollis DP, Economou JS, Parks LC, Eggleston JC, Saryan LA, Czeister JL. Nuclear magnetic resonance studies of several experimental and human malignant tumors. *Cancer Res*. Sep 1973;33(9):2156-2160.

53. Hazlewood CF, Cleveland G, Medina D. Relationship between hydration and proton nuclear magnetic resonance relaxation times in tissues of tumor-bearing and non-tumor-bearing mice: implications for cancer detection. *J Natl Cancer Inst.* Jun 1974;52(6):1849-1853.
54. Norden AD, Young GS, Setayesh K, et al. Bevacizumab for recurrent malignant gliomas: efficacy, toxicity, and patterns of recurrence. *Neurology.* Mar 4 2008;70(10):779-787.
55. Pai A, Li X, Majumdar S. A comparative study at 3 T of sequence dependence of T2 quantitation in the knee. *Magn Reson Imaging.* Nov 2008;26(9):1215-1220.
56. Wintersperger BJ, Runge VM, Biswas J, Reiser MF, Schoenberg SO. Brain tumor enhancement in MR imaging at 3 Tesla: comparison of SNR and CNR gain using TSE and GRE techniques. *Invest Radiol.* Aug 2007;42(8):558-563.
57. Akeson P, Nordstrom CH, Holtas S. Time-dependency in brain lesion enhancement with gadodiamide injection. *Acta Radiol.* Jan 1997;38(1):19-24.
58. Ellingson BM, Malkin MG, Rand SD, et al. Validation of functional diffusion maps (fDMs) as a biomarker for human glioma cellularity. *J Magn Reson Imaging.* Mar 2010;31(3):538-548.
59. Sugahara T, Korogi Y, Kochi M, et al. Usefulness of diffusion-weighted MRI with echo-planar technique in the evaluation of cellularity in gliomas. *J Magn Reson Imaging.* Jan 1999;9(1):53-60.
60. Chenevert TL, Stegman LD, Taylor JM, et al. Diffusion magnetic resonance imaging: an early surrogate marker of therapeutic efficacy in brain tumors. *J Natl Cancer Inst.* Dec 20 2000;92(24):2029-2036.

- 61.** Guo AC, Cummings TJ, Dash RC, Provenzale JM. Lymphomas and high-grade astrocytomas: comparison of water diffusibility and histologic characteristics. *Radiology*. Jul 2002;224(1):177-183.
- 62.** Padhani AR, Liu G, Koh DM, et al. Diffusion-weighted magnetic resonance imaging as a cancer biomarker: consensus and recommendations. *Neoplasia*. Feb 2009;11(2):102-125.

TABLE 1: MINIMUM STANDARD 1.5T & 3T MRI PROTOCOL

	3D T1w Pre ^b	Ax 2D FLAIR ^j	Ax 2D DWI	Contrast Injection ^a	Ax 2D T2w ^{h,i}	3D T1w Post ^b	
Sequence	IR-GRE ^{e,f}	TSE ^c	SS-EPI ^g			TSE ^c	IR-GRE ^{e,f}
Plane	Sagittal/ Axial	Axial	Axial			Axial	Sagittal/Axial
Mode	3D	2D	2D			2D	3D
TR [ms]	2100 ^m	>6000	>5000			>2500	2100 ^m
TE [ms]	Min	100-140	Min			80-120	Min
TI [ms]	1100 ⁿ	2000-2500 ^k					1100 ⁿ
Flip Angle	10°-15°	90°/≥160°	90°/180°			90°/≥160°	10°-15°
Frequency	≥172	≥256	≥128			≥256	≥172
Phase	≥172	≥256	≥128			≥256	≥172
NEX	≥1	≥1	≥1			≥1	≥1
FOV	256mm	240mm	240mm			240mm	256mm
Slice Thickness	≤1.5mm	≤4mm ^l	≤4mm ^l			≤4mm ^l	≤1.5mm
Gap/Spacing	0	0	0			0	0
Diffusion Options^p			<i>b</i> = 0, 500, 1000 s/mm ² ≥3 directions				
Parallel Imaging	Up to 2x	Up to 2x	Up to 2x			Up to 2x	Up to 2x
Scan Time (Approx) [Benchmarked on 3T Skyra]	5-10 min [5:49 for 1mm isotropic]	4-8 min [3:22 for 2D FLAIR]	2-4 min [1:22 for 3 direction DWI and 3 b-values]			4-8 min [5:10 for dual echo]	5-10 min [5:49 for 1mm isotropic]

- ^a 0.1 mmol/kg dose injection with a Gadolinium chelated contrast agent. Use of a power injector is desirable at an injection rate of 3-5cc/sec.
- ^b Post-contrast 3D T1-weighted images should be collected with equivalent parameters to pre-contrast 3D T1-weighted images
- ^c TSE = turbo spin echo (Siemens & Philips) is equivalent to FSE (fast spin echo; GE, Hitachi, Toshiba)
- ^d FL2D = two-dimensional fast low angle shot (FLASH; Siemens) is equivalent to the spoil gradient recalled echo (SPGR; GE) or T1- fast field echo (FFE; Philips), fast field echo (FastFE; Toshiba), or the radiofrequency spoiled steady state acquisition rewind gradient echo (RSSG; Hitachi). A fast gradient echo sequence without inversion preparation is desired.
- ^e IR-GRE = inversion-recovery gradient-recalled echo sequence is equivalent to MPRAGE = magnetization prepared rapid gradient-echo (Siemens & Hitachi) and the inversion recovery spoiled gradient-echo (IR-SPGR or Fast SPGR with inversion activated or BRAVO; GE), 3D turbo field echo (TFE; Philips), or 3D fast field echo (3D Fast FE; Toshiba).
- ^f A 3D acquisition without inversion preparation will result in different contrast compared with MPRAGE or another IR-prepped 3D T1-weighted sequences and therefore should be avoided.
- ^g In the event of significant patient motion, a radial acquisition scheme may be used (e.g. BLADE [Siemens], PROPELLER [GE], MultiVane [Philips], RADAR [Hitachi], or JET [Toshiba]); however, this acquisition scheme is can cause significant differences in ADC quantification and therefore should be used only if EPI is not an option. Further, this type of acquisition takes considerable more time.
- ^h Dual echo PD/T2 TSE is optional for possible quantification of tissue T2. For this sequence, the PD echo is recommended to have a TE < 25ms.
- ⁱ Advanced sequences can be substituted into this time slot, so long as 3D post-contrast T1-weighted images are collected between 4 and 8 min after contrast injection.
- ^j 3D FLAIR is an optional alternative to 2D FLAIR, with sequence parameters as follows per EORTC guidelines: 3D TSE/FSE acquisition; TE=90-140ms; TR=6000-10000ms; TI=2000-2500ms (chosen based on vendor recommendations for optimized protocol and field strength); GRAPPA≤2; Fat Saturation; Slice thickness ≤ 1.5mm; Orientation Sagittal or Axial; FOV ≤ 250 mm x 250 mm; Matrix ≥ 244x244.
- ^k Choice of TI should be chosen based on the magnetic field strength of the system (e.g. TI ≈ 2000ms for 1.5T and TI ≈ 2500ms for 3T).
- ^l In order to ensure comparable SNR older 1.5T MR systems can use contiguous (no interslice gap) images with 5mm slice thickness or increase NEX for slice thickness ≤4mm.
- ⁿ For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TI = 400-450ms for similar contrast.
- ^m For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TR = 5-15ms for similar contrast.
- ^p Older model MR scanners that are not capable of >2 *b*-values should use *b* = 0 and 1000 s/mm².

Acronyms:

Ax = Axial; ADC = apparent diffusion coefficient. FLAIR = fluid attenuated inversion recovery; DWI = diffusion-weighted imaging; 3D = three dimensional; TSE = turbo spin echo; EPI = echo planar imaging; SS-EPI = single-shot echo planar imaging; GE-EPI = gradient echo echo planar imaging; 2DFL = two-dimensional FLASH (fast low angle shot) gradient recalled echo; MPRAGE = magnetization prepared rapid gradient-echo; A/P = anterior to posterior; R/L = right to left; NEX = number of excitations or averages; FOV = field of view; TE = echo time; TR = repetition time; TI = inversion time; PD = proton density; DSC = dynamic susceptibility contrast; IR-GRE = inversion-recovery gradient-recalled echo

TABLE 2: RECOMMENDED 3T PROTOCOL

	3D T1w Pre	Ax 2D FLAIR	Ax 2D DWI	Contrast Injection^a	Ax 2D T2w	3D T1w Post^b
Sequence	IR-GRE ^{d,e}	TSE ^c	EPI ^f		TSE ^c	IR-GRE ^{d,e}
Plane	Sagittal/Axial	Axial	Axial		Axial	Axial/Sagittal
Mode	3D	2D	2D		2D	3D
TR [ms]	2100 ^g	>6000	>5000		>2500	2100 ^g
TE [ms]	Min	100-140	Min		80-120	Min
TI [ms]	1100 ^h	2500				1100 ^h
Flip Angle	10°-15°	90°/≥160°	90°/180°		90°/≥160°	10°-15°
Frequency	256	≥256	128		≥256	256
Phase	256	≥256	128		≥256	256
NEX	≥1	≥1	≥1		≥1	≥1
FOV	256mm	240mm	240mm		240mm	256mm
Slice Thickness	1mm	3mm	3mm		3mm	1mm
Gap/Spacing	0	0	0	0	0	
Diffusion Options			<i>b</i> = 0, 500, and 1000 s/mm ² ≥3 directions			
Parallel Imaging	Up to 2x	Up to 2x	Up to 2x	Up to 2x	Up to 2x	
Scan Time (Approx)	5-8 min	4-5 min	3-5 min	3-5 min	5-8 min	

^a 0.1 mmol/kg or up to 20cc (single, full dose) of MR contrast.

^b Post-contrast 3D axial T1-weighted images should be collected with identical parameters to pre-contrast 3D axial T1-weighted images

^c TSE = turbo spin echo (Siemens & Philips) is equivalent to FSE (fast spin echo; GE, Hitachi, Toshiba)

^d IR-GRE = inversion-recovery gradient-recalled echo sequence is equivalent to MPRAGE = magnetization prepared rapid gradient-echo (Siemens & Hitachi) and the inversion recovery spoiled gradient-echo (IR-SPGR or Fast SPGR with inversion activated or BRAVO; GE), 3D turbo field echo (TFE; Philips), or 3D fast field echo (3D Fast FE; Toshiba).

^e A 3D acquisition without inversion preparation will result in different contrast compared with MPRAGE or another IR-prepped 3D T1-weighted sequences and therefore should be avoided.

^f In the event of significant patient motion, a radial acquisition scheme may be used (e.g. BLADE [Siemens], PROPELLER [GE], MultiVane [Philips], RADAR [Hitachi], or JET [Toshiba]); however, this acquisition scheme is can cause significant differences in ADC quantification and therefore should be used only if EPI is not an option.

^g For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TR = 5-15ms for similar contrast.

^h For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TI = 400-450ms for similar contrast.

Acronyms:

Ax = Axial; ADC = apparent diffusion coefficient. FLAIR = fluid attenuated inversion recovery; DWI = diffusion-weighted imaging; 3D = three dimensional; TSE = turbo spin echo; EPI = echo planar imaging; MPRAGE = magnetization prepared rapid gradient-echo; A/P = anterior to posterior; R/L = right to left; NEX = number of excitations or averages; FOV = field of view; IR-GRE = inversion-recovery gradient-recalled echo

TABLE 3: RECOMMENDED 1.5T PROTOCOL

	3D T1w Pre	Ax 2D FLAIR	Ax 2D DWI	Contrast Injection ^a	Ax 2D T2w	3D T1w Post ^b	
Sequence	IR-GRE ^{d,e}	TSE ^c	EPI ^f			TSE ^c	IR-GRE ^{d,e}
Plane	Sagittal/Axial	Axial	Axial			Axial	Sagittal/Axial
Mode	3D	2D	2D			2D	3D
TR [ms]	2100 ^g	>6000	>5000			>3500	2100 ^g
TE [ms]	Min	100-140	Min			100-120	Min
TI [ms]	1100 ^h	2200					1100 ^h
Flip Angle	10°-15°	90°/≥160°	90°/180°			90°/≥160°	10°-15°
Frequency	≥172	≥256	128			≥256	≥172
Phase	≥172	≥256	128			≥256	≥172
NEX	≥1	≥1	≥1			≥1	≥1
FOV	256mm	240mm	240mm			240mm	256mm
Slice Thickness	≤1.5mm	≤4mm	≤4mm			≤4mm	≤1.5mm
Gap/Spacing	0	0	0			0	0
Diffusion Optionsⁱ			<i>b</i> = 0, 500, and 1000 s/mm ² ≥3 directions				
Parallel Imaging	No	Up to 2x	Up to 2x			Up to 2x	No
Scan Time (Approx)	5-10 min	4-5 min	3-5 min		3-5 min	5-10 min	

^a 0.1 mmol/kg or up to 20cc (single, full dose) of MR contrast.

^b Post-contrast 2D axial T1-weighted images should be collected with identical parameters to pre-contrast 2D axial T1-weighted images

^c TSE = turbo spin echo (Siemens & Philips) is equivalent to FSE (fast spin echo; GE, Hitachi, Toshiba)

^d IR-GRE = inversion-recovery gradient-recalled echo sequence is equivalent to MPRAGE = magnetization prepared rapid gradient-echo (Siemens & Hitachi) and the inversion recovery spoiled gradient-echo (IR-SPGR or Fast SPGR with inversion activated or BRAVO; GE), 3D turbo field echo (TFE; Philips), or 3D fast field echo (3D Fast FE; Toshiba).

^e A 3D acquisition without inversion preparation will result in different contrast compared with MPRAGE or another IR-prepped 3D T1-weighted sequences and therefore should be avoided.

^f In the event of significant patient motion, a radial acquisition scheme may be used (e.g. BLADE [Siemens], PROPELLER [GE], MultiVane [Philips], RADAR [Hitachi], or JET [Toshiba]); however, this acquisition scheme is can cause significant differences in ADC quantification and therefore should be used only if EPI is not an option.

^g For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TR = 5-15ms for similar contrast.

^h For Siemens and Hitachi scanners. GE, Philips, and Toshiba scanners should use a TI = 400-450ms for similar contrast.

ⁱ Older model MR scanners that are not capable of >2 *b*-values should use *b* = 0 and 1000 s/mm².

Acronyms:

Ax = Axial; ADC = apparent diffusion coefficient. FLAIR = fluid attenuated inversion recovery; DWI = diffusion-weighted imaging; 3D = three dimensional; TSE = turbo spin echo; EPI = echo planar imaging; MPRAGE = magnetization prepared rapid gradient-echo; A/P = anterior to posterior; R/L = right to left; NEX = number of excitations or averages; FOV = field of view; IR-GRE = inversion-recovery gradient-recalled echo